

KAWASAKI BRUTE FORCE 650/750

Plow Mount

PART #106655 Rev A

Kit Components:

Item #	Qty.	Description
1	1	Plow Mount Plate (106652)
2	1	Hardware Kit (HK-111)
2.1	4	5/16"-18 x 1-1/4" x 2" U-Bolt
2.2	8	5/16-18 Hex Flange Lock Nut

NOTICE Torque bolts to ANSI Specs (or OEM specs if applicable), unless otherwise stated. After the first use and at the start of each season, check torque.

Note: Make sure all hardware needed to complete this mount is in the package. Thoroughly read through and understand the instructions.

INSTALLATION INSTRUCTIONS

Step 1: Remove the Skid Plate or Drill Holes

1. Remove 4 bolts (A) from the skid plate and remove the skid plate. *Figure 1*

Note: If you prefer to leave your skid plate attached, you may drill holes for the u-bolts (*Figure 2*) and continue to Step 2.

Step 2: Install the Plow Mount

1. Place u-bolts (2.1) on machine frame as shown. *Figure 2*
2. Install mount plate loosely to frame using the u-bolts (2.1) and 5/16" flange lock nuts (2.2). *Figures 3 and 4*
3. Adjust plate so oil plug lines up with hole and plate is centered on machine.
4. Tighten down all nuts, making sure u-bolt ends are even.

